Trouble	Cause	Remedy
	Telescopic Fork	
Knocks in front fork	Play of steering column bearings;	Tighten the bearings to remove the play;
	tubes of fork blades playing in the traverse due to clamp nuts being loose;	tighten nuts to remove the play;
	absence or lack of oil in fork blades;	trace the cause of oil leakage; eliminate leakage; fill oil into fork;
	clearance between the check nut and upper tip of spring is too great;	set the clearance as required;
	bushings of fork blade tubes much worn out	replace worn-out parts
	Shock Absorbers	
Shock absorbers are leaky	Rod gland much worn;	Replace the gland;
	sealing ring damaged;	fit a new ring;
	rod worn out	install a new rod
Abnormal wobbling of rear suspension	Insufficient amount or low viscosity of damping fluid in shock absorbers;	Overhaul shock absorbers, wash and fill with appropriate fluid;
	upper piston valve does not fit closely or lower valve of shock absorber does not seat properly;	overhaul shock absorber and wash it, if necessary, lap the valve and piston end face;
	piston, rod, tube worn out	replace worn-out parts
Obstructed operation of rear suspension	Damping fluid is very viscous;	Use fluid of appropriate viscosity;
	dosing ducts on the piston or lower valve of shock absorber clogged	dismantle shock absorbers and wash
	Electrical Equipment	
Ignition key is inserted to the full extent and turned to the right: battery charge control lamp, indicator lamp of gearshift mechanism neutral position and oil pressure warning lamp will not light up (with the engine inoperative), no sound of horn	Fuse in block ПР11В ("+" of storage battery) blown; violated contact in connections: terminal "+" of storage battery — block of fuses ПР11В, terminal "+" of generator — block of fuses ПР11В, terminal "1" of master switch	
When changing engine speed from low to higher, charge control lamp does not extinguish (glows steadily)	Generator fails to develop the required voltage, reverse-current relay does not operate	Check the generator and current-and-voltage regulator wires for proper connection check the generator and current-and-voltage regulator for good condition

Downloaded from www.Manualslib.com manuals search engine