| Sketch | Type and No. of bearing | Bearing description and point of installation | Q'ty per motorcycle |
|---|---|---|---|
|  | 42209<br>Radial roller bearing with short cylindrical rollers | Rear roller bearing of crank gear. In the engine crankcase | 1 |
|  | 303<br>Single-row radial ball bearing | Bearing of gear box primary shaft | 1 |
|  | 304<br>Single-row radial ball bearing | Secondary shaft bearing. In front cover of gear box casing and in casing | 2 |
|  | 7204A<br>Single-row tapered roller bearing | Wheel roller bearing. In the wheel hub | 8 |
|  | 874901<br>Needle bearing | Bearing of driving gear of main drive. In main drive casing and on driving gear of main drive | 1 |
|  | 3086304Л<br>Double-row radial thrust ball bearing | Bearing on driving gear of main drive and casing | 1 |



Downloaded from www.Manualslib.com manuals search engine