Continued

List of compulsory maintenance jobs	Tools and accessories to be used	Materials used in maintenance	Ref. No. in lubrication chart (Fig. 44)
Check adjustment of clutch release mechanism	Screwdriver, feeler gauge		
Check adjustment of wheel bearings and change around wheels	Driver's tools		
Check steering column bearing adjustment			
Remove nuts which fasten the exhaust tubes to cylinder heads and lubricate the thread		Graphite lubricant БВН-1 GOST 5656—60	
Change oil in engine	Filler funnel	Oil AC-8 GOST 10541—63; the following grades of oils are recommended for use: in summer — М-12Г (No. 8) in winter—М8Г (No. 9) or all-weather oil М-10Г ТУ38-1-267-69. Change oil after every 5000 km run	
Check oil level in gear box and fill up if necessary	Feeler gauge, funnel	Refer to Technical Servicing (TS) No. 2	*10*
Check oil level in main drive casing. If necessary, add oil.	Feeler gauge, funnel	Refer to TS No. 2	*7*
Check tightening of body vibration arrester	Driver's tools		

Technical Servicing No. 2

Carry out all the jobs of Technical Servicing No. 1			
Remove carbon from spark plugs and check the size of clearance between electrodes (clearance should be 0.5 to 0.6 mm)	Feeler gauge		
Change oil in gear box casing	Filler funnel, dipstick	Oil AC-8 GOST 10541—63. Use may be made of oil ТАД-17 with periodicity of change after 10000 km run	
Lubricate the rear wheel brake drive hinges	Grease gun	Lubricant Lithol-24* GOST 21150—75	*8*
Lubricate the rear brake cam axle	Grease gun	Lithol-24 GOST 21150—75	
Change oil in main drive	Filler funnel, dipstick	Oil for hypoid gears GOST 4003—53. Use may be made of oil ТАД-17 with periodicity of change after 10000 km run	

* Never mix lubricant Lithol-24 with other oils.

Downloaded from www.Manualslib.com manuals search engine