List of compulsory maintenance jobs	Tools and accessories to be used	Materials used in maintenance	Ref. No. in lubrication chart (Fig. 44)
Check all the wires for reliable connection and electrical equipment insulation for good condition			
Lubricate the pins of clutch lever and hand brake lever, speedometer drive cable and felt brush of contact breaker		Lithol-24 GOST 21150—75 Oil AC-8 GOST 10541—63	*14* *1* *11*
Check and adjust the toe- in and camber angle of motorcycle and sidecar wheels (toe-in should be equal to 10 mm, camber angle — 2 deg)	Lath, plumb bob		
Make sure that the rubber springs of the sidecar are properly tightened	Driver's tools		
Wash out petrol cock sump, fuel filter	Driver's tools	Petrol	
Dismantle the front brake, wash its parts in kerosene, blow through with air, lubricate friction surfaces. Remove excessive lubricant		Kerosene, lubricant Lithol-24 GOST 21150—75	*12*
Take off, disassemble and wash the carburettor, blow through the carburettor jets and ducts	Driver's tools		

Technical Servicing No. 3

Carry out all the jobs of Technical Servicing No. 2			
Take off the spring-and-hydraulic absorbers of rear suspension and of sidecar wheel, dismantle them partially, rinse, assemble and charge with fresh damping fluid. If necessary, change rubber sealing rings		Mixture of 50% turbine oil 22 (turbine oil Л) GOST 32—74 and 50% transformer oil GOST 982—68, kerosene	*5*
Remove carbon deposit from the surface of combustion chambers and check the valves for tightness and lap them, if required	Driver's tools		
Change oil in front wheel shock absorbers, wash the inner cavity of the telescopic fork with the same oil		Oil AC-8 GOST 10541—63	*5*
Lubricate the collet clamps of the sidecar		Lithol-24 GOST 21150—75	*16*
Lubricate the steering column plummer bearings	Grease gun	Lubricant Lithol-24 GOST 21150—75	*2*
Take off the wheels, dismantle them, remove used grease from the hub, wash bearings in kerosene and blow through with air, lubricate them by hand, assemble, check and adjust tightening of bearings	Driver's tools	Kerosene, lubricant Lithol-24 GOST 21150—75	

Downloaded from www.Manualslib.com manuals search engine